


Thomsen Ice Edger Electric Start Assembly



Use only genuine **Thomsen** replacement parts

Item No.	Part No.	Description	No. Req'd
130	31-31IL	Lock-Washer	2
131	31-31CW	Washer.....	2
132	10-32ESNA	Nut	2
133	18-148	Tank Tray	1
134	18-148-01	Battery Holder.....	1
135	10-3202FH	Flat Hd. Screw	2
136	31-1810	Bolt.....	2
137	18-550	12 Volt Battery	1
138	18-148-02	Battery Tie Down Rod	2
139	18-148-03	Battery Hold Down Strap	1
140	10-24ESNA	Nut	2
141	18-170-01	Electric Starter Cover.....	1
142	18-555	PRO-18ES Electric Start Wiring Harness.....	1
	18-560	T-18ES Electric Start Wiring Harness	1
143	18-175	Battery Tray (Gas Option)	1